



# Hart Engineering Corporation

**SUBMITTAL:**  
11310-02

**PROJECT:** 9722. - Veolia/Taunton WWTP Solids Handling Improvements

**DATE:** 11/10/2021

**SUBMITTAL:** 11310-02 - Thickened Sludge Grinder O&M Manual

**REVISION:** A

**STATUS:** Eng

**SPEC #:** 11310

**TO:**  
**Carl Hendrickson**  
Veolia North America  
125 S. 84th Street, Suite 175  
Milwaukee, WI 53214  
carl.hendrickson@veolia.com

**FROM:**  
**Ryan Murphy**  
Hart Engineering Corporation  
800 Scenic View Drive  
Cumberland, RI 02864  
rmurphy@hartcompanies.com

Item	Revision	Description	Status	Date Sent	Date Returned
11310-02	A	Thickened Sludge Grinder O&M Manual	Eng	11/10/2021	
Notes:					

Additional Notes:

**Status Codes**

- 1-APP – No Exceptions Taken
- 2-ANR – Make Corrections Noted
- 3-R&R – Revise and Resubmit
- 4-REJ – Rejected
- 5-IPO – For Information Purposes Only
- 6-NRR – Not Required for Review
- ENG – Submitted to Engineer

Sincerely,  
Hart Engineering Corporation

DATE: \_\_\_\_\_ 11/10/2021 \_\_\_\_\_



## **OPERATION and MAINTENANCE MANUAL**

### **Taunton, MA WWTF Solids Handling Improvements**

#### **MUFFIN MONSTER GRINDER**

Model 10000-0806

Serial Nos. 115242-1-1, 115242-1-2

#### **MOTOR CONTROLLER**

Model PC2220

Serial Nos. 115242-2-1, 115242-2-2

#### **Contractor**

Hart Engineering Corporation  
800 Scenic View Drive  
Cumberland, RI 02864-8706

#### **Manufacturer/Service**

JWC Environmental  
2600 South Garnsey Street  
Santa Ana, CA 92707  
Ph: 800-331-2277

#### **Local Representative**

Aqua Solutions  
154 West Grove Street Unit D  
Middleboro, MA 02346  
Ph: 508-947-5777



# **OVERALL TABLE OF CONTENTS**

## **Taunton, MA WWTF Solids Handling Improvements**

- Customer Order
- Terms and Conditions
- Reconditioning Service Policy

### **TAB 1**

- Operation and Maintenance Manual, Grinder Model 10000-0806
- Drawings

### **TAB 2**

- Operation and Maintenance Manual, Motor Controller PC2220
- Drawings





2850 S. Red Hill Ave., STE 125  
 Santa Ana, CA 92705  
 (949) 833-3888

**CUSTOMER ORDER**

Order Number: **115242**  
 Date: **11/6/2021**  
 Page: **1**

**Sold To**

Hart Engineering Corporation  
 800 Scenic View Dr  
 Cumberland, RI 02864-8706  
 US - UNITED STATES

**Ship To**

Hart Engineering  
 825 West Water Street  
 Taunton, MA 02780  
 US - UNITED STATES

CUSTOMER ID	CUSTOMER P.O.	PAYMENT TERMS	FREIGHT TERMS			
6002363	9722.102	90% Net 30 Days; 10% NTE 90 Day	Freight Prepaid			
SALES REP ID	SHIPPING METHOD	F.O.B.	SHIP DATE			
Aqua Solutions	Bestway	Origin	11/11/2021			
QUANTITY			T			
LI #	ORD	SHP	LOT	PART ID	DESCRIPTION	T
						X

Name & number trucker can call 24 hours prior delivery:  
 Brian Little 401-302-0092

Days & hours of delivery: M\_F 7-3  
 Is lift gate or forklift needed for truck: No will have a forklift/lull on site

LIQUIDATED DAMAGES apply – capped at 15%

1 2 0 1 10000-0806-DI  
 10000-CD REV D  
 A10000 REV D

10000-0806-DI  
 Ship Date 11/11/2021  
 Model 10000-0806-DI Muffin Monster grinder in a 6 inch dia. pipeline.  
 10000-0806-DI grinder with 8 inch cutter stack using 11 tooth .310 thick cam cutters in alloy steel tungsten carbide mechanical seals with Buna-N elastomers rated for 90 psi, Cork & Rubber gaskets.  
 30010-0144 - 3HP TEFC 208-230/460V 182TC 1.15SF

Hunter Green Epoxy  
 SN: 115242-1-1, 115242-1-2

2 2 0 2 PC2200

PC2220-115242  
 Ship Date 11/11/2021  
 DWG. #PC2220-115242-A  
 3HP Grinder Motor  
 460V/ 3PH/ 60Hz  
 Panasonic PLC  
 Allen-Bradley pilot devices  
 Remote mode status contact  
 One Set of Spare Fuses  
 NEMA 4X Fiberglass Enclosure (18x16x10)  
 Program #PC2220-001-A

SN: 115242-2-1, 115242-2-2



2850 S. Red Hill Ave., STE 125  
 Santa Ana, CA 92705  
 (949) 833-3888

**CUSTOMER ORDER**

Order Number: **115242**  
 Date: **11/6/2021**  
 Page: **2**

**Sold To**

Hart Engineering Corporation  
 800 Scenic View Dr  
 Cumberland, RI 02864-8706  
 US - UNITED STATES

**Ship To**

Hart Engineering  
 825 West Water Street  
 Taunton, MA 02780  
 US - UNITED STATES

CUSTOMER ID	CUSTOMER P.O.	PAYMENT TERMS	FREIGHT TERMS				
6002363	9722.102	90% Net 30 Days; 10% NTE 90 Day	Freight Prepaid				
SALES REP ID	SHIPPING METHOD	F.O.B.	SHIP DATE				
Aqua Solutions	Bestway	Origin	11/11/2021				
QUANTITY			T				
LI #	ORD	SHIP	LOT	PART ID	DESCRIPTION	T	X

3	3	0		SUBMITTALS	Standard Submittals Ship Date 11/11/2021 For approval:  (1) PDF to George, Christiaan (CGeorge@hartcompanies.com) (1) PDF Rep: Warren Brown <wbrown@aquasolutionsinc.net (1) PDF Rep: James Deluca <jdeluca@aquasolutionsinc.net		
4	8	0		MANUALS	O&M MANUALS HARD COPY Ship Date 11/11/2021 Standard manuals Ship separately:  (1) PDF to George, Christiaan (CGeorge@hartcompanies.com) (1) PDF Rep: Warren Brown <wbrown@aquasolutionsinc.net (1) PDF Rep: James Deluca <jdeluca@aquasolutionsinc.net (5) Final copies of complete manuals to customer 9attn: Jim Ramos		
5	1	0		Shipping	Shipping & Handling Ship Date 11/11/2021		
6	1	0		SU	Start Up Ship Date 11/11/2021 One (1) day of start-up supervision by a factory-authorized representative.		
7	1	0		TARIFF	Tariff Surcharge Ship Date 11/11/2021		

JWC ENVIRONMENTAL  
TERMS AND CONDITIONS OF SALE

Unless otherwise specifically agreed to in writing by the buyer ("Buyer") of the products and or related services purchased hereunder (the "Products") and JWC Environmental (the "Seller"), the sale of the Products is made only upon the following terms and conditions. Whether these terms are included in an offer or an acceptance by Seller, such offer or acceptance is conditioned on Buyer's assent to these terms. Seller rejects all additional, conditional and different terms in Buyer's form or documents.

#### PAYMENT TERMS

Subject to any contrary terms set forth in our price quotation, order acceptance or invoice the full net amount of each invoice is due and payable in cash within 30 days from the date of the invoice. If any payment is not received within such 30-day period, Buyer shall pay Seller the lesser of 1 ½% per month or the maximum legal rate on all amounts not received by the due date of the invoice, from the 31st day after the date of invoice until said invoice and charges are paid in full. Unless Seller's documents provide otherwise, freight, storage, insurance and all taxes, duties or other governmental charges related to the Products shall be paid by the Buyer. If Seller is required to pay any such charges, Buyer shall immediately reimburse Seller for said charges. In all cases, regardless of partial payment, title to the Products shall remain the Seller's until payment for the Products has been made in full. All orders are subject to credit approval by Seller. All offers by Seller and/or acceptance of Buyer's order shall be nullified by any failure of Buyer to obtain credit approval. Furthermore, Buyer shall not assert any claim against Seller due to Buyer's inability to obtain credit approval. Irrevocable Letter of Credit from Buyer in form and term acceptable to Seller is required for Product orders delivered outside the United States of America.

#### DELIVERY

Unless otherwise provided in our price quotation, delivery of the Products shall be made F.O.B. place of manufacture. Any shipment, delivery, installation or service dates quoted by the Seller are estimated and the Seller shall be obligated only to use reasonable efforts to meet such dates. The Seller shall in no event be liable for any delays in delivery or failure to give notice of delay or for any other failure to perform hereunder due to causes beyond the reasonable control of the Seller. Such causes shall include, but not be limited to, acts of God, the elements, acts or omissions of manufacturers or suppliers of the Products or parts thereof, acts or omissions of Buyer or civil and military authorities, fires, labor disputes or any other inability to obtain the Products, parts thereof, or necessary power, labor, materials or supplies. The Seller will be entitled to refuse to make, or to delay, any shipments of the Products if Buyer shall fail to pay when due any amount owed by it to the Seller, whether under this or any other contract between the Seller and Buyer. Any claims for shortages must be made to the Company in writing within five calendar days from the delivery date and disposition of the claim is solely subject to Seller's determination.

#### PRICES

Prices of the Seller's Products are subject to change without notice. Quotations are conditioned upon acceptance within 30 days unless otherwise stated and are subject to correction for errors and/or omissions. Prices include charges for regular packaging but, unless expressly stated, do not include charges for special requirements of government or other purchaser. Prices are subject to adjustment should Buyer place an order past the validity period of the quotation or delay delivery of Products beyond the quoted lead time for any reason.

#### RETURNS

No Products may be returned for cash. No Product may be returned for credit after delivery to Buyer without Buyer first receiving written permission from the Seller. Buyer must make a request for return of Product in writing to Seller at its place of business in Costa Mesa, California. A return material authorization number must be issued by the Seller to the Buyer before a Product may be returned. Permission to return Product to Seller by Buyer is solely and exclusively the Seller's. Product must be returned to Seller at Buyer's expense, including packaging, insurance, transportation and any governmental fees. Any credit for Product returned to Seller shall be subject to the inspection of and acceptance of the Product by the Seller and is at the sole discretion of the Seller.

#### LIMITED WARRANTY

Subject to the terms and conditions hereof, the Seller warrants until one year after commissioning (written notification to Seller by Buyer required) of the Product or until 18 months after delivery of such Product to Buyer, whichever is earlier, that each Product will be free of defects in material and workmanship. If (a) the Seller receives written notification of such defect during the warranty period and the defective Products use is discontinued promptly upon discovery of alleged defect, and (b) if the owner ("Owner") forwards the Product to the Seller's nearest service/repair facility, transportation and related insurance charges prepaid. The Seller will cause any Products whose defect is covered under this warranty to either be replaced or be repaired at no cost to the Owner. The foregoing warranty does not cover repairs required due to repair or alteration other than by the Seller's personnel, accident, neglect, misuse, transportation or causes other than ordinary use and maintenance in accordance with the Seller's instructions and specifications. In addition, the foregoing warranty does not cover any Products, or components thereof, which are not directly manufactured by the Seller. To the extent a warranty for repair or replacement of such Products or components not manufactured directly by the Seller is available to Buyer under agreements of the Seller with its vendors, the Seller will make such warranties available to Buyer. Costs of transportation of any covered defective item to and from the nearest service/repair center and related insurance will be paid or reimbursed by Buyer. Any replaced Products will become the property of the Seller. Any replacement Products will be warranted only for any remaining term of the original limited warranty period and not beyond that term.

#### DISCLAIMER OF WARRANTIES AND LIMITATIONS OF LIABILITIES

THE SELLER'S FOREGOING LIMITED WARRANTY IS THE EXCLUSIVE AND ONLY WARRANTY WITH RESPECT TO THE PRODUCTS AND SHALL BE IN LIEU OF ALL OTHER WARRANTIES (OTHER THAN THE WARRANTY OF TITLE), EXPRESS, STATUTORY OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND ANY STATEMENTS MADE BY EMPLOYEES, AGENTS OF THE SELLER OR OTHERS REGARDING THE PRODUCTS. THE OBLIGATIONS OF THE SELLER UNDER THE FOREGOING WARRANTY SHALL BE FULLY SATISFIED BY THE REPAIR OR THE REPLACEMENT OF THE DEFECTIVE PRODUCT OR PART, AS PROVIDED ABOVE. IN NO EVENT SHALL THE SELLER BE LIABLE FOR LOST PROFITS OR OTHER SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, EVEN IF THE SELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE TOTAL LIABILITY OF THE SELLER TO BUYER AND OTHERS ARISING FROM ANY CAUSE WHATSOEVER IN CONNECTION WITH BUYER'S PURCHASE, USE AND DISPOSITION OF ANY PRODUCT COVERED HEREBY SHALL, UNDER NO CIRCUMSTANCES, EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT BY BUYER. NO ACTION, REGARDLESS OF FORM, ARISING FROM THIS AGREEMENT OR BASED UPON BUYER'S PURCHASE, USE OR DISPOSITION OF THE PRODUCTS MAY BE BROUGHT BY EITHER PARTY MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION ACCRUES, EXCEPT THAT ANY CAUSE OF ACTION FOR THE NONPAYMENT OF THE PURCHASE PRICE MAY BE BROUGHT AT ANY TIME.

The remedies provided to Buyer pursuant to the limited warranty, disclaimer of warranties and limitations of liabilities, described herein are the sole and exclusive remedies.

Unless specifically agreed to in writing by the Seller, no charges may be made to the Seller by Buyer or any third party employed by buyer for removing, installing or modifying any Product.

The Seller and its representatives may furnish, at no additional expense, data and engineering services relating to the application, installation, maintenance or use of the Products by Buyer. The Seller will not be responsible for, and does not assume any liability whatsoever for, damages of any kind sustained either directly or indirectly by any person through the adoption or use of such data or engineering services in whole or in part.

#### CONFIDENTIAL INFORMATION

Except with the Seller's prior written consent, Buyer shall not use, duplicate or disclose any confidential proprietary information delivered or disclosed by the Seller to Buyer for any purpose other than for operation or maintenance of the Products.

#### CANCELLATION AND DEFAULT

Absolutely no credit will be allowed for any change or cancellation of an order for Products by Buyer after fabrication of the Products to fill Buyer's order has been commenced. If Buyer shall default in paying for any Products purchased hereunder, Buyer shall be responsible for all reasonable costs and expenses, including (without limitation) attorney's fees incurred by the Seller in collecting any sums owed by Buyer. All rights and remedies to the Seller hereunder or under applicable laws are cumulative and none of them shall be exclusive of any other right to remedy. No failure by the Seller to enforce any right or remedy hereunder shall be deemed to be a waiver of such right or remedy, unless a written waiver is signed by an authorized management employee of the Seller and the Seller's waiver of a breach of this agreement by Buyer shall not be deemed to be a waiver of any other breach of the same or any other provision.

#### CHANGES IN PRODUCTS

Changes may be made in materials, designs and specifications of the Products without notice. The Seller shall not incur any obligation to furnish or install any such changes or modifications on Products previously ordered by, or sold to, Buyer.

#### APPLICABLE LAW, RESOLUTION OF DISPUTES AND SEVERABILITY

This agreement is entered into in Costa Mesa, California. This agreement and performance by the parties hereunder shall be construed in accordance with, and governed by, the laws of the State of California. Any claim or dispute arising from or based upon this agreement or the Products which form its subject matter shall be resolved by binding arbitration before the American Arbitration Association in Los Angeles, California, pursuant to the Commercial Arbitration Rules, excepting only that each of the parties shall be entitled to take no more than two depositions, and serve no more than 30 interrogatories, 10 requests for admissions and 20 individual requests for production of documents, such discovery to be served pursuant to the California Code of Civil Procedure. Any award made by the arbitrator may be entered as a final judgment, in any court having jurisdiction to do so. If any provision of this agreement shall be held by a court of competent jurisdiction or an arbitrator to be unenforceable to any extent, that provision shall be enforced to the full extent permitted by law and the remaining provisions shall remain in full force and effect.

#### ASSIGNMENT

This agreement shall be binding upon the parties and their respective successors and assigns. However, except for rights expressly provided to subsequent Owners of the Products under "Limited Warranty" above, any assignment of this agreement or any rights hereunder by Buyer shall be void without the Company's written consent first obtained. Any exercise of rights by an Owner other than Buyer shall be subject to all of the limitations on liability and other related terms and conditions set forth in this agreement.

#### EXCLUSIVE TERMS AND CONDITIONS

The terms and conditions of this agreement may be changed or modified only by an instrument in writing signed by an authorized management employee of the Seller. This instrument, together with any amendment or supplement hereto specifically agreed to in writing by an authorized management employee of the Seller, contains the entire and the only agreement between the parties with respect to the sale of the Products covered hereby and supercedes any alleged related representation, promise or condition not specifically incorporated herein.

SELLER'S PRODUCTS ARE OFFERED FOR SALE AND SOLD ONLY ON THE TERMS AND CONDITIONS CONTAINED HEREIN. NOTWITHSTANDING ANY DIFFERENT OR ADDITIONAL TERMS OR CONDITIONS CONTAINED IN BUYER'S SEPARATE PURCHASE ORDERS OR OTHER ORAL OR WRITTEN COMMUNICATIONS, BUYER'S ORDER IS OR SHALL BE ACCEPTED BY THE COMPANY ONLY ON THE CONDITION THAT BUYER ACCEPTS AND CONSENTS TO THE TERMS AND CONDITIONS CONTAINED HEREIN. IN THE ABSENCE OF BUYER'S ACCEPTANCE OF THE TERMS AND CONDITIONS CONTAINED HEREIN, THE SELLER'S COMMENCEMENT OF PERFORMANCE AND/OR DELIVERY OF THE PRODUCTS, OR THE SELLER'S STATEMENT OF ACKNOWLEDGMENT OF THE RECEIPT OF BUYER'S PURCHASE ORDER, SHALL BE FOR BUYER'S CONVENIENCE ONLY AND SHALL NOT BE DEEMED OR CONSTRUED TO BE ACCEPTANCE OF BUYER'S DIFFERING TERMS OR CONDITIONS, OR ANY OF THEM. ANY DIFFERENT OR ADDITIONAL TERMS ARE HEREBY REJECTED UNLESS SPECIFICALLY AGREED UPON IN WRITING BY AN AUTHORIZED MANAGEMENT EMPLOYEE OF THE SELLER. IF A CONTRACT IS NOT EARLIER FORMED BY MUTUAL AGREEMENT IN WRITING, BUYER'S ACCEPTANCE OF ANY PRODUCTS COVERED HEREBY SHALL BE DEEMED ACCEPTANCE OF ALL OF THE TERMS AND CONDITIONS STATED HEREIN. THE SELLER'S FAILURE TO OBJECT TO PROVISIONS INCONSISTENT HEREWITH CONTAINED IN ANY COMMUNICATION FROM BUYER SHALL NOT BE DEEMED A WAIVER OF THE PROVISIONS CONTAINED HEREIN.





**JWC Environmental**  
**2600 South Garnsey Street**  
**Santa Ana, California 92707**  
**Phone: 949-833-3888**

## **Reconditioning Service**

### **1. Free Labor**

Under the Free Labor Reconditioning Policy, JWC Environmental provides free labor services on refurbishing all Muffin Monster® grinders. When the work is performed by factory personnel at the JWC Environmental service center, there is no labor charge for the reconditioning or replacement of any product component manufactured by JWC Manufacturing (excluding motor, reducer and controllers). The customer pays only for shipping and parts. Upon receipt, the unit will be disassembled and all parts will be factory inspected. After inspection but before commencing work, JWC Environmental® provides a quote on required replacement parts.

### **Advantages Under This Policy Include:**

- New One Year Factory Warranty
- The Latest Design or Specification Change for Maximum Service Life
- Improved Reliability Avoid Uncertainties and Delays Often Associated with Self-Repair
- Reduce Your Maintenance Man-Hours
- Reduce Your Life Cycle Ownership Costs
- Reduce Your Parts Inventory

### **2. Cutter Cartridge Exchange**

Another option is the Cutter Cartridge Exchange Program. Muffin Monster owners can order a factory reconditioned cutter cartridge in exchange for their unit requiring reconditioning. Subject to availability, the replacement cartridge will be shipped in response to a user's request. The factory exchange cutter cartridge is invoiced at a not to exceed price.

In addition to the advantages of the free labor services listed above, the exchange program results in significant reduction of machine down time.

### **3. Limited Warranty**

Reconditioned units are backed by a limited one (1) year warranty for material and workmanship. This warranty covers the reconditioned cutter cartridge only (excludes motor, reducer, and controller).

### **JWC Environmental Sales /Service**

2600 South Garnsey Street  
Santa Ana, CA 92707  
(714) 825-1960  
(800) 331-2277  
Fax (714) 549-4007

# **JWC ENVIRONMENTAL**

**CHANNEL MONSTER® / MACHO MONSTER / MUFFIN MONSTER® /  
MINI MONSTER® / SLUDGE MONSTER®**

## **OPERATION AND MAINTENANCE MANUAL**

**This manual, and all the information contained herein, is the exclusive property of JWC Environmental. It is fully protected by copyright and contains information of a proprietary nature. It is provided for the sole purpose of transmitting the information contained herein to the designated recipient.**

**This information is to be used only as specified in the JWC Environmental Terms and Conditions of the identified sales order and only for the operation and maintenance of the Products which it was designed for. It is not to be reproduced, copied in whole, or in part, nor is the information it contains to be disclosed in any manner without the written consent of JWC Environmental. Its use for any other reason than that specified shall be in violation of the agreement with the recipient concerning the legal rights of JWC Environmental.**

**JWC Environmental reserves the right to make changes which may obsolete certain parts of this manual.**

**© 2021 JWC Environmental ALL RIGHTS RESERVED**

**JWCE, JWC Environmental, Muffin Monster, Channel Monster, Mini Monster, Macho Monster, and Sludge Monster are registered trademarks of JWC Environmental Inc.**

**JWCE's Santa Ana and Costa Mesa California facilities are registered by UL to ISO9001:2008 #10001313 QM8. JWC International Congleton, UK is registered by QAS to ISO9001:2008 File #A13056. U.S. patents apply: 4,919,346; 5,060,872; 5,320,286; 5,333,801; 5,354,004; 5,478,020; 5,505,388; 5,593,100; 6,176,443; 6,332,984; 7,073,433; 7,080,650; 7,081,171; 7,086,405; 7,383,842; RE37,550E; RE37,349E; RE40,422; RE39,948E. Additional patents pending and international patents also apply.**

**Other product and company names herein may be the trademarks of their respective owners.**

**No part of this document may be photocopied, reproduced, stored in a retrieval system, or transmitted, in any form or by any means whether, electronic, mechanical, or otherwise without the prior written permission of JWCE.**

**No warranty of accuracy is given concerning the contents of the information contained in this publication. To the extent permitted by law no liability (including liability to any person by reason of negligence) will be accepted by JWCE, its subsidiaries or employees for any direct or indirect loss or damage caused by omissions from or inaccuracies in this document.**

**JWCE reserves the right to change details in this publication without notice.**







# OPERATION and MAINTENANCE MANUAL

## Muffin Monster® 10000

### In-Line Grinder

October 2019

JWC Environmental Inc.  
2600 S. Garnsey  
Santa Ana, CA 92707

[www.jwce.com](http://www.jwce.com)



JWC Environmental Inc. shall not be liable for any commercial losses, loss of revenues or profits, loss of goodwill, inconvenience, or exemplary, special, incidental, indirect or consequential damages whatsoever, or claims of third parties, regardless of the form of any claim that may result from the use of this practice.



## TABLE OF CONTENTS

### SECTION 1 GENERAL INFORMATION

1.1 PREFACE .....	1-1
1.2 INTRODUCTION .....	1-1
1.3 DESCRIPTION .....	1-1
1.4 LIMITATION OF USE .....	1-2
1.5 DESIGN COMPLIANCE .....	1-2
1.6 REPAIRS AND RETURNS .....	1-2

### SECTION 2 SAFETY INSTRUCTIONS

2.1 INTRODUCTION .....	2-1
------------------------	-----

### SECTION 3 INSTALLATION AND CHECKOUT

3.1 INTRODUCTION .....	3-1
3.2 UNPACKING AND STORAGE .....	3-1
3.3 INSTALLATION .....	3-1
3.4 STARTUP .....	3-2
3.5 LONG TERM AND PERMANENT SHUTDOWNS .....	3-2
3.5.1 Long Term Shutdown (but less than 1 year) .....	3-2
3.5.2 Permanent Shutdown .....	3-2

### SECTION 4 MAINTENANCE

4.1 INTRODUCTION .....	4-1
4.2 MAINTENANCE REQUIREMENTS .....	4-1
4.3 INSPECTION/MAINTENANCE .....	4-2
4.3.1 Visual .....	4-2
4.3.2 External Fasteners .....	4-2
4.3.3 Drive Assembly .....	4-2
4.3.4 Cutter Stack .....	4-2
4.4 LUBRICATION .....	4-2
4.4.1 Grinder Drive Couplings .....	4-2
4.4.2 Drive Gears .....	4-3
4.5 PARTS INFORMATION .....	4-3

### SECTION 5 TROUBLESHOOTING

5.1 INTRODUCTION .....	5-1
------------------------	-----

## TABLE OF CONTENTS (Cont'd)

### SECTION 6 ASSEMBLY, REMOVAL AND REPLACEMENT

6.1 INTRODUCTION.....	6-1
6.2 MUFFIN MONSTER 10000 ASSEMBLY .....	6-1
6.2.1 Assembly Top End Housing .....	6-2
6.2.2 Install Cutters and Spacers .....	6-2
6.2.3 Prepare Main Housing.....	6-3
6.2.4 Attach Main Housing to Top Housing.....	6-4
6.2.5 Install Bottom Cover .....	6-4
6.2.6 Top Cover Installation.....	6-5
6.2.7 Drive Motor Installation.....	6-5
6.3 GRINDER REMOVAL .....	6-6
6.4 GRINDER COMPONENT REPLACEMENT .....	6-6
6.4.1 Main Body Removal and Replacement .....	6-6
6.4.2 Cutter and Spacer Removal .....	6-6
6.4.3 Stacking Cutters and Spacers .....	6-7
6.4.4 Gear and Shaft Removal and Replacement.....	6-7
6.4.5 Top End Housing Removal.....	6-7
6.4.6 Seal Cartridge - Top, Inspection and Removal.....	6-8
6.4.7 Seal Cartridge - Bottom, Inspection and Removal .....	6-8
6.5 GRIND TEST.....	6-8
6.6 OPTIONAL MOTOR/REDUCER ASSEMBLY.....	6-8

APPENDIX A ELECTRIC DRIVE ASSEMBLY MAINTENANCE INSTRUCTIONS.....	A-1
------------------------------------------------------------------	-----



## LIST OF FIGURES

Figure 1-1 MUFFIN MONSTER 10000 4" FLANGE DIMENSIONS .....	1-1
Figure 1-2 MUFFIN MONSTER 10000 6" FLANGE DIMENSIONS - B .....	1-1
Figure 1-3 MUFFIN MONSTER 10000 4" SIDE DIMENSIONS - C .....	1-2
Figure 1-4 MUFFIN MONSTER 10000 6" SIDE DIMENSIONS .....	1-2
Figure 3-1 INSTALLATION CONFIGURATIONS .....	3-1
Figure 3-2 SUGGESTED CLEARANCE .....	3-1
Figure 3-3 GRINDER LIFT POINTS .....	3-2
Figure 6-1 TOP END HOUSING .....	6-2
Figure 6-2 GEAR INSTALLATION .....	6-2
Figure 6-3 CUTTER/SPACER STACKING .....	6-3
Figure 6-4 CUTTER ORIENTATION .....	6-3
Figure 6-5 MAIN HOUSING .....	6-3
Figure 6-6 MAIN HOUSING TO TOP HOUSING ATTACHMENT .....	6-4
Figure 6-7 BOTTOM COVER INSTALLATION .....	6-4
Figure 6-8 TOP COVER INSTALLATION .....	6-5
Figure 6-9 DRIVE MOTOR INSTALLATION .....	6-5
Figure 6-10 LIFTING WITH HOIST .....	6-6
Figure 6-11 OPTIONAL MOTOR/REDUCER DIMENSIONS .....	6-8
Figure 6-12 OPTIONAL TEFC, SUPER-E, WASHDOWN, XPFC MOTOR/REDUCER - EXT SHAFT ...	6-9
Figure 6-13 IMMERSIBLE MOTOR .....	6-9
Figure 6-14 MUFFIN MONSTER 10000 EXPLODED VIEW .....	6-10

This page intentionally left blank

## LIST OF TABLES

Table 1-1 GRINDER SPECIFICATIONS .....	1-3
Table 1-2 GRINDER MATERIALS (Configuration Dependent) .....	1-3
Table 1-3 GRINDER CHARACTERISTICS .....	1-3
Table 4-1 INSPECTION AND LUBRICATION SCHEDULE .....	4-1
Table 4-2 RECOMMENDED LUBRICANTS .....	4-1
Table 5-1 GRINDER TROUBLESHOOTING GUIDE .....	5-1
Table 5-2 GRINDER MOTOR TROUBLESHOOTING GUIDE .....	5-3
Table 6-1 ELECTRIC MOTOR DIMENSIONS .....	6-9
Table 6-2 MUFFIN MONSTER 10000 PARTS LIST .....	6-11

This page intentionally left blank

## SECTION 1 GENERAL INFORMATION

### 1.1 PREFACE

This information is the property of JWC Environmental and contains proprietary data. It is not to be reproduced or copied in part, or in whole, without the written consent of JWC Environmental.

The specifications and information in this document are subject to change without notice. Actual equipment performance may vary based on individual configurations, conditions, or other factors.

### 1.2 INTRODUCTION

SECTION 1 describes and defines the specifications and support information related to the Muffin Monster 10000 grinder. Figures 1-1, 1-2, 1-3 and 1-4 show a standard 4" and 6" configuration grinder and corresponding dimensions.

### 1.3 DESCRIPTION


The grinder is a two shafted in-line grinding system designed for installation on the suction side of pumps that pulverizes influent solids into a particle size acceptable to sewage type pumps. Solids reduction facilitates free flow and easy disposal of sludge, eliminating the need for treatment plant bar screens, rakes, and other related equipment.

The other components of a typical grinding system are a motor drive mounted to the grinder that provides rotary power for the grinder shafts. Also, a separate motor controller provides operator and automatic controls for the grinder motor. Refer to the corresponding manual or instruction list for details on other components.


MUFFIN MONSTER 10000 technical information grinder:

- Motor options
  - 2 HP (1.5 kW) electric gearmotor
  - 3 HP (2.2 kW) electric gearmotor
  - 2 HP electric motor/speed reducer
  - 3 HP electric motor/speed reducer
- Max. flow: 555 GPM (35 L/S) - 6" flanges
- Maximum working pressure: 90 PSI (620 kPa)
- 6" flange application


**FIGURE 1-1 MUFFIN MONSTER 10000 4" FLANGE DIMENSIONS**



**FIGURE 1-2 MUFFIN MONSTER 10000 6" FLANGE DIMENSIONS - B**



**FIGURE 1-3 MUFFIN MONSTER 10000 4" SIDE DIMENSIONS - C**



**FIGURE 1-4 MUFFIN MONSTER 10000 6" SIDE DIMENSIONS**




Table 1-1 shows standard grinder configuration specifications; Table 1-2 shows the grinder material.

#### 1.4 LIMITATION OF USE

JWCE considers that the buyers and users of this equipment limit the use of the equipment to the purpose and intent defined at the time of sale. Applications of the equipment other than defined must be in compliance with all applicable local, federal, and area safety rules, regulations, and guidelines.

#### 1.5 DESIGN COMPLIANCE

JWCE considers the equipment described in this manual as satisfying the design criteria for same and/or similar types of equipment. JWCE also considers that the buyers and users of this equipment comply and ensure compliance with the warnings, cautions and notes included in this manual to avoid the potential for injury and/or equipment damage.

#### 1.6 REPAIRS AND RETURNS

Return Authorization must be obtained by calling JWCE if repairs are required. Be prepared to provide the model number and serial number which are located on the nameplate on the grinder top cover. Returned item(s) must be securely packaged and shipped to JWCE.

Contact JWCE Customer Service or a local sales/service representative for international shipping or questions regarding service.

**JWC Environmental**  
2600 S. Garnsey St.  
Santa Ana, CA 92707

**800-331-2277**  
**949-833-3888**  
**714-549-4007 (fax)**

**TABLE 1-1 GRINDER SPECIFICATIONS**

Horsepower	3
Motor Type	Electric Motor / Speed Reducer
Motor Configuration	TEFC
Voltage	460 VAC
Frequency	60Hz
Duty	Continuous
Temperature Rating	Operating 23°F (-5°C) to 105°F (40°C) Storage 40°F (5°C) to 105°F (40°C)
Speed Reducer Ratio	29:1
Cutters	11 tooth, 4¾" (120 mm) diameter
Enclosure	Fiberglass

**TABLE 1-2 GRINDER MATERIALS (Configuration Dependent)**

GRINDER COMPONENT	MATERIAL USED
End Housings	ASTM A536 ductile iron
Top and Bottom Covers	ASTM A536 ductile iron
Cutters and Spacers	Alloy steel
Shafts	AISI 4140 alloy steel, 2" (50 mm) hex
Seal Faces	Tungsten Carbide with Buna-N elastomers

**TABLE 1-3 GRINDER CHARACTERISTICS**

MODEL	FLOW RATE	PIPELINE SIZE	PRESSURE DROP	APPROXIMATE WEIGHT
10000-0804	275 gpm	4 in	0.36 psi	303 lbs
10000-0806	550 gpm	6 in	1.33 psi	323 lbs

This page intentionally left blank.




## SECTION 2 SAFETY INSTRUCTIONS


### 2.1 INTRODUCTION

Operations and maintenance personnel must read and understand the safety instructions listed in this section and throughout this manual before operating or maintaining the grinder. **WARNINGS** (double boxed, upper case), **Cautions** (single boxed, title case), and **NOTES** inform operations and maintenance personnel of safety concerns and important information crucial to the operation and maintenance of this equipment.


Safety instructions are based on properly trained personnel using good safety practices at all times. JWC Environmental shall not be held liable for any ignorance or disregard of applicable OSHA, federal, state, or local regulations. JWC Environmental shall not be held liable for any damages resulting from controller functions that are triggered as a result of wiring misconnections, wiring shielding errors, and/or other wiring errors not in compliance with OSHA, federal, state, or local regulations.




**DO NOT WEAR LOOSE FITTING CLOTHING NEAR JWCE EQUIPMENT.**




**KEEP PERSONNEL AND UNAUTHORIZED MATERIAL CLEAR OF GRINDER CUTTING CHAMBER.**




**WEAR EYE AND EAR PROTECTION WHEN STEAM CLEANING ANY COMPONENTS.**



**DO NOT LIFT HEAVY EQUIPMENT OVERHEAD OF PERSONNEL. ENSURE THAT ADEQUATE ASSISTANCE IS AVAILABLE AND UTILIZED WHEN LIFTING AND TRANSPORTING EQUIPMENT, TOOLS, AND SUPPORT EQUIPMENT/MATERIALS.**



**ELECTRICAL HAZARDS EXIST. DO NOT TAKE ELECTRICAL MEASUREMENTS ALONE. VERIFY AND ENSURE POWER TO THE MOTOR CONTROLLER IS REMOVED, LOCKED OUT, AND TAGGED BEFORE PERFORMING ANY INSTALLATION, SERVICE, OR MAINTENANCE TASK INCLUDING REMOVAL OR ATTEMPTING REMOVAL OF ANY OBSTRUCTION FROM THE GRINDER.**



**JWCE CONTROLLER PANEL CONTROLS DO NOT REMOVE POWER FROM THE CONTROLLER ENCLOSURE. DO NOT USE ANY START/STOP PUSHBUTTON AS A POWER DISCONNECT. SERVICE JWCE CONTROLLERS AND CONNECTED DEVICES ONLY WHEN POWER TO THE CONTROLLER HAS BEEN TURNED OFF, LOCKED OUT AND TAGGED.**



**DO NOT ATTEMPT ANY MAINTENANCE ON THE EQUIPMENT DURING A POWER LOSS. THE GRINDER MAY START, STOP, REVERSE, OR AUTOMATICALLY RESTART AFTER POWER LOSS AND RECOVERY. ELECTRICAL LOCKOUT PROCEDURES MUST BE PERFORMED PRIOR TO SERVICING ANY EQUIPMENT OR CONNECTED EQUIPMENT.**



**PERSONAL AND MECHANICAL HAZARDS EXIST DURING THE PERFORMANCE OF THE GRIND TEST.**



**PERFORM ALL SURFACE PREPARATION AND PAINTING IN A WELL VENTILATED NON-SMOKING AREA THAT IS IN COMPLIANCE WITH ALL APPLICABLE SAFETY REGULATIONS. AVOID PROLONGED EXPOSURE TO VAPORS. USE AN AIR RESPIRATOR/AIR MASK AND CHEMICAL SAFETY GOGGLES/FACE SHIELD.**



**CUTTERS AND SPACERS ARE SHARP. APPROPRIATE GLOVES MUST BE WORN WHEN INSTALLING OR HANDLING CUTTERS AND SPACERS TO PREVENT INJURY DURING HANDLING.**

## SECTION 3 INSTALLATION AND CHECKOUT

### 3.1 INTRODUCTION

SECTION 3 describes installation, checkout, and start-up procedures for the MUFFIN MONSTER 10000 grinder. Review all safety instructions before installing the grinder.

No special equipment is required for grinder installation, only ensure any lifting and handling device is rated for a load capacity greater than the weight of the grinder (approx. weight 200 lbs/90.7 kg).

### 3.2 UNPACKING AND STORAGE

The grinder is carefully packaged for shipment to the installation site. Do not remove any components from the shipping crate/carton until an inventory is taken.

1. Inspect the shipping container. Immediately report any shipping container damage to the carrier and send a copy to the company representative.
2. Inspect the grinder for missing, loose, or damaged components. The grinder is shipped completely assembled and ready to install. Contact JWCE or an authorized factory representative if parts are loose, missing, or damaged.
3. Inspect the grinder options included with the order. If parts are loose, missing, or damaged contact JWCE or an authorized factory representative.
4. After inspection for shortages and damage close all shipping containers. Store the equipment indoors in the shipping containers in an environment between 40° F (5° C) and 105° F (40° C) until time for installation. Do not re-open the storage container until installation.

The gear motor has been lubricated at the factory. Extended storage may cause grease to separate. A small amount of light oil may leak from greased areas. Unless leakage is excessive (i.e., more than one [1] tablespoon) it does not cause any problems. The grease homogenizes to its original consistency when the gears are run.

For equipment storage exceeding three (3) months prior to installation, contact JWCE Sales Support for storage instructions.

### 3.3 INSTALLATION


Perform the following procedure to install the grinder in line with the existing piping. A minimum

amount of civil work is required during installation. Standard tools, a multimeter and lifting equipment with the proper load rating are all that is required - no special tools. All drive components are factory greased and ready for operation. Figures 3-1, 3-2, and 3-3 show the configurations, clearance, and grinder lift points. Use this information in your installation considerations. Remember, approximate grinder weight is 200 lbs/90.7 kgs.


A minimum of five pipe diameters should be allowed between the grinder discharge and the pump suction if the grinder is installed upstream of a pump.

Read and understand the appropriate motor controller manual before operating the grinder.


**FIGURE 3-1 INSTALLATION CONFIGURATIONS**



**FIGURE 3-2 SUGGESTED CLEARANCE**



**FIGURE 3-3 GRINDER LIFT POINTS**



1. Verify that electrical power to the grinder is shut off and tagged out.
2. Locate the flow directional arrows on the main housing. Arrows point in the direction of flow.
3. Attach lifting cables to the lifting lugs as shown in Figure 3-3 to move the grinder into its installation position.
4. Install the flange gaskets and bolt the grinder flanges to their mating flanges in the pipe system. Bolts and gaskets are supplied by others.
5. Connect the electrical power from the grinder drive assembly to the motor controller panel. Refer to the motor controller schematic in the associated motor controller O&M manual and the site installation drawing during installation.
6. Verify that all electrical and mechanical connections are connected and secure. Complete any required customer/user inspection records and forms.

### 3.4 STARTUP

As has been stated, the motor controller controls grinder operation. Refer to the associated motor controller manual to perform grinder startup.

Verify correct rotation of the cutters by either of the two following methods:

*Method 1* - Remove the upstream inspection port plug and visually verify that cutter rotation is converging into the center of the cutter stack. See Figure 6-4 for reference.

*Method 2* - Inspect the rotation of the fan on the motor. The fan will be rotating in opposite direction - away from the center - of the cutter stack. This means the shafts (and therefore the cutters) will be converging toward the center of the stack as desired.

### 3.5 LONG TERM AND PERMANENT SHUTDOWNS

This section describes the steps to perform if the grinder is to be removed from service either permanently or for an extended time. For shutdowns longer than one (1) year, contact JWCE Customer Service for instructions.

#### 3.5.1 Long Term Shutdown (but less than 1 year)

For a long term shutdown remove and lock out electrical power to the motor controller and isolate the grinder from both upstream and downstream flow.

For shutdowns from six (6) months up to one (1) year perform the following procedure.

1. Remove the grinder from its installation site if possible.
2. Steam clean all parts except the drive assemblies and clean the grinder using an appropriate solvent.
3. Rotate the grinder drive assembly for one (1) to five (5) minutes every three (3) months. If the grinder cannot be operated manually, temporarily apply the appropriate power to the grinder drive assembly for one (1) to five (5) minutes. Check for lubricant leakage.

#### 3.5.2 Permanent Shutdown

The following guidelines should be followed when the grinder is being permanently taken out of service.

If returning to JWCE, clean and disinfect the grinder prior to crating for return.

For on-site disposal, clean and disinfect the grinder and components. Disassemble the grinder as described in SECTION 6. Dispose of the motor and components in accordance with local, federal, and national safety and disposal regulations and standards. Apply warning and safety labels to materials and containers where required.

## SECTION 4 MAINTENANCE

### 4.1 INTRODUCTION

SECTION 4 defines maintenance guidelines and identifies the lubricants and procedures required to support the MUFFIN MONSTER 10000 grinder. Review all safety instructions before performing maintenance on the grinder. Refer to SECTION 5 for troubleshooting guidelines. Refer to SECTION 6 for removal and replacement instructions, the grinder exploded view, and the parts list. Refer to the appropriate manuals for motor controller and drive maintenance and troubleshooting information. Contact JWCE Customer Support or a local service representative for any maintenance information questions.

a summary of maintenance tasks (including lubrication) and Table 4-2 for a list of recommended lubricants.

Contact JWCE Customer Support or a local service representative for questions on lubrication requirements, guidelines, or recommended lubricants. Avoid mixing brands and/or types of lubricants. Contact JWCE if the lubricant identified does not meet requirements.

### 4.2 MAINTENANCE REQUIREMENTS

The following paragraphs describe the scheduled grinder maintenance activities. Recommended maintenance is required to ensure the grinder operates in optimal condition. Refer to Table 4-1 for

Tasks are written for personnel experienced in same and/or similar equipment who are familiar with the basic operation, safety, emergency procedures, general plant safety, and use of plant tools/maintenance equipment. Time periods are based on normal operation usage and can be adjusted by the individual users depending on equipment usage and the operational environment. More frequent inspections may be required for grinders operating in a harsh environment or processing corrosive or abrasive material.

**TABLE 4-1 INSPECTION AND LUBRICATION SCHEDULE**

TASK	SCHEDULE	REFERENCE
Visual inspection	Monthly	Paragraph 4.3.1
Inspect/tighten external fasteners	At startup, then every year	Paragraph 4.3.2
Inspect drive assembly	At startup, then every year	Paragraph 4.3.3
Inspect cutter stack	At startup, then every year	Paragraph 4.3.4
Lubricate grinder drive couplings	Every 5 years	Paragraph 4.4.1
Lubricate drive gears	Every 5 years	Paragraph 4.4.2

**TABLE 4-2 RECOMMENDED LUBRICANTS**

TASK	TYPE	MANUFACTURER
Cutter stack lubrication	Zep 45 Aerosol Lubricant* WD-40 Aerosol Lubricant	Zep 45 Manufacturing WD-40 Corp.
O-ring and seal cartridge replacement	MPG All Purpose Super Grease*	Nichels Engineering
Greasing of couplings and drive gears	Mystic JT-6 Hi-Temp* Lubriplate 930-AA Mobiltemp 1, 2 or 78 Industrial Grease	Citgo Fiske Bros. Refining Mobil Oil Chevron Texaco
Grinder long term service removal	LPS 3® Rust Inhibitor*	LPS Laboratories
*OEM recommended		


### 4.3 INSPECTION/MAINTENANCE

The following paragraphs describe the inspection guidelines, preparation for inspection, and the inspection/maintenance defined for the grinder. Refer to the motor controller manual for inspection guidelines and procedures. Refer to SECTION 6 for removal/replacement instructions, grinder exploded view and grinder parts list.


Observe the following guidelines during maintenance:




**OPEN, LOCK OUT, AND TAG OUT POWER TO THE CONTROLLER PER SAFETY PROCEDURES.**



**ISOLATE FLOW THROUGH THE PIPELINE AS REQUIRED TO AVOID INJURY AND/OR DAMAGE FROM FLOW PRESSURES AND/OR INFLUENT. RELIEVE PRESSURE BY CRACKING OPEN ONE OF THE GRINDER FLANGES.**



**KEEP PERSONNEL AND UNAUTHORIZED MATERIAL CLEAR OF GRINDER CUTTING CHAMBER.**

- Clean gasket surfaces of all gasket material before installing a new gasket.
- Thoroughly clean end housing bores with solvent (methyl ethyl ketone [MEK], acetone or equivalent). Replace housing if bores are scored, pitted, or other damage is identified.
- Replace cracked parts and any part that shows signs of excessive wear.
- Avoid mixing brands and/or types of lubricants. For questions regarding lubricants contact JWCE Customer Support.
- Rinse and steam sanitize the grinder parts except the drive assembly. Use solvent to clean the exterior of the drive assembly.

- Complete all required customer/user inspection records and forms.

#### 4.3.1 Visual

Check the grinder for leakage, vibration, noise, or solids buildup on cutters and side rails, especially cloth or paper wrapping. Check grinder output for proper solids reduction.

#### 4.3.2 External Fasteners

Check grinder external fasteners, especially gasket and flange fasteners, and tighten if loose.

#### 4.3.3 Drive Assembly

Check that the grinder drive is free of contaminants and that there is no sign of damage, overheating or lubricant leakage. Check the hardware securing the drive to the grinder for tightness.

#### 4.3.4 Cutter Stack

Isolate grinder from flow and remove the upstream inspection port to check the cutter stack. Check cutters for damage or wear. Damaged or worn cutters must be replaced if solids are not being properly reduced or if the grinder jams excessively.

Check cutter stack tightness by inserting a long screwdriver or similar tool in between adjacent cutters on each shaft and moving the tool up and down. Verify none of the cutters or spacers shift along the shaft when pressure is exerted. Cutters must be removed, cleaned, restacked and lubricated if any cutters or spacers shift along the shafts.

### 4.4 LUBRICATION

Observe the following when lubricating the grinder:

- Set the motor controller grinder switch to OFF and open any motor controller circuit breaker or disconnect switch. Remove, lock out and tag out supply power before lubricating any component.
- Avoid mixing brands and/or types of lubricants.
- Complete customer/user inspection records and forms if required.

#### 4.4.1 Grinder Drive Couplings

Remove the drive per SECTION 6 instructions. Carefully remove old grease if required and

replace with new grease per Table 4-2 and Paragraph 6.2.7.

#### **4.4.2 Drive Gears**

Remove top cover per SECTION 6 instructions. Carefully remove old grease and replace with new grease per Table 4-2. Replace top cover.

#### **4.5 PARTS INFORMATION**

The parts list included in SECTION 6 identifies the parts for the standard configuration of the Muffin Monster 10000 grinder. JWCE does not recommend the stocking of replaceable parts as spares but rather recommends the user refer to the JWCE FREE LABOR POLICY for an alternative to stocking parts which may or may not be used.

This page intentionally left blank.




## SECTION 5 TROUBLESHOOTING


### 5.1 INTRODUCTION

SECTION 5 describes MUFFIN MONSTER 10000 grinder troubleshooting. Review all safety instructions before troubleshooting the grinder. Table 5-1 is a troubleshooting guide for the grinder itself; Table 5-2 is a troubleshooting guide for the grinder motor. Refer to SECTION 6 for the appropriate removal and replacement instructions based on troubleshooting results. Refer to the motor controller and drive manuals for causes and possible solutions for problems not related to the grinder.

The grinder normally operates smoothly and quietly. Verify main power is available before troubleshooting. Power off and tag out main power to the motor controller if any excessive noise or temperature rise is observed and, importantly, prior to any grinder inspection operation.



**PERSONAL AND MECHANICAL HAZARDS EXIST WHEN THE GRINDER IS RUNNING. POWER OFF AND TAG OUT GRINDER PRIOR TO TROUBLESHOOTING.**



**ELECTRICAL HAZARDS EXIST WHEN TAKING VOLTAGE AND CURRENT MEASUREMENTS. DO NOT TAKE ELECTRICAL MEASUREMENTS ALONE.**

**TABLE 5-1 GRINDER TROUBLESHOOTING GUIDE**

Symptom	Possible Cause	Solution
Grinder making noise.	Cutter stack loose.	Check stack tightness. If loose, remove, inspect, clean, and tighten. Replace any damaged or worn cutters and spacers.
	Damaged cutter(s) or spacer(s).	Replace damaged cutter(s) or spacer(s).
	Seal or bearing failure.	Replace failed grinder seal cartridge.
	Drive gears not sufficiently greased.	Clean and re-grease gears (replace gears if damaged or excessive gear wear has occurred).
	Motor bearing or reducer may require grease.	Contact JWCE.
Cutter drive shaft not rotating.	Broken drive shaft below drive gear.	Replace drive shaft and check for ancillary damage. Return part to JWCE.
Cutter driven shaft not rotating.	Driven gear key failure.	Replace key if broken or missing. Contact factory if gear or shaft keyway is damaged.
	Broken driven shaft.	Replace driven shaft and check for ancillary damage (return to factory).

**TABLE 5-1 GRINDER TROUBLESHOOTING GUIDE (Cont'd)**

Both cutter drive and driven shafts not rotating.	Drive coupling failure; drive lugs worn.	Replace coupling assembly.
	Broken drive shaft.	Replace drive shaft and check for ancillary damage. Return part to JWCE.
	Grinder gearmotor failure.	Replace gearmotor.
	Grinder motor coupling key failure (applies only to drives with separate motor/reducer).	Replace coupling key(s) if broken or missing. Contact JWCE if shaft keyways are damaged.
	Grinder motor coupling failure (applies only to drives with separate motor/reducer).	Replace coupling assembly. Check coupling keys for damage or wear.
Head drop across grinder excessive.	Downstream water conditions different from what was originally provided at application stage.	Refer to performance flow curve to determine required flow conditions. Contact JWCE for assistance.
	Cutting stack clogged with debris.	Remove debris from cutters. Replace cutters if excessive wear is found.
	Solids content of sludge higher than expected.	Reduce solids loading or decrease duty cycle.
Grinder reverses excessively, but continues to run.	Cutters are worn and cannot effectively grind material.	Replace cutters and spacers.
	Excessive solids loading or duty cycle.	Reduce solids loading or decrease duty cycle.
	Grinder current sensor reverse threshold set too low.	Contact JWCE for assistance.
	Excessive friction on components.	Refer to Symptom - <i>Grinder making noise</i> .
Debris buildup on drive shaft spacers.	Cutters excessively worn.	Replace worn cutters.
Motor controller indicates Grinder Overload.	Unusually large or troublesome solids entered grinder chamber.	Locate and remove troublesome solids from waste stream. Reset controller and restart grinder per the controller O&M.
	Excessive solids loading or duty cycle.	Reduce solids loading or decrease duty cycle.
	Cutters excessively worn.	Replace worn cutters.
Motor controller indicates Grinder Motor Overload. The grinder motor current draw exceeds duration established by the controller.	Excessive solids loading or duty cycle.	Reduce solids loading or decrease duty cycle.
	Excessive friction on components.	Refer to Symptom - <i>Grinder making noise</i> .

**TABLE 5-2 GRINDER MOTOR TROUBLESHOOTING GUIDE**

Symptom	Possible Cause	Solution
Motor does not start.	Line trouble such as single phasing at motor starter.	Check power source, overloads, fuses, controls, etc.
Excessive humming.	High voltage.	Check line connections.
	Eccentric air gap.	Contact factory to have motor serviced.
Motor overheating.	Overloading of motor due to excessive friction or duty cycle.	Remove unwanted friction in motor; reduce the duty cycle of equipment.
	Single phasing or unbalanced voltage.	Verify the current for each motor leg. The current for each leg should be approximately equal - if not, isolate and correct.
	Improper ventilation.	Verify cooling fan is operating correctly; increase ventilation of motor; reduce ambient heat on motor.
	Rotor rubbing on stator.	Contact JWCE to have motor serviced.
	Over or under voltage.	Check input voltage on each leg.
	Open stator winding.	Check voltage on all legs.
	Grounded winding.	Perform dielectric test and repair as required.
Improper connections.	Inspect all electrical connections for proper termination, clearance, mechanical strength, and electrical continuity. Refer to motor lead connections.	


This page intentionally left blank.

## SECTION 6 ASSEMBLY, REMOVAL AND REPLACEMENT



### 6.1 INTRODUCTION

SECTION 6 describes the MUFFIN MONSTER 10000 grinder assembly and component removal and replacement. Review all safety instructions before removing and replacing grinder assembly or components. Grinder components can be reused unless broken or worn. Contact JWCE Sales Support for questions regarding grinder service.


The following guidelines must be observed when assembling and installing, or removing and reinstalling the grinder.



**ISOLATE THE GRINDER FROM FLOW THROUGH THE PIPELINE AND RELIEVE ANY REMAINING PRESSURE.**

**OPEN, LOCKOUT, AND TAG POWER AT THE DISCONNECT (OR CIRCUIT BREAKER) TO THE CONTROLLER BEFORE ANY DISASSEMBLY OR REASSEMBLY PROCEDURES.**




**WEAR EYE AND EAR PROTECTION WHEN STEAM CLEANING ANY COMPONENTS. COMPLY WITH ALL OSHA AND OTHER REGULATORY AGENCY SAFETY REQUIREMENTS.**



**DO NOT WEAR LOOSE FITTING CLOTHING NEAR THE GRINDER.**




**USE EXTREME CARE WHEN USING ANY SOLVENT.**



**CUTTERS AND SPACERS ARE SHARP. APPROPRIATE GLOVES MUST BE WORN WHEN INSTALLING OR HANDLING CUTTERS AND SPACERS TO PREVENT INJURY DURING HANDLING.**

### 6.2 MUFFIN MONSTER 10000 ASSEMBLY


The following procedures describe how to assemble a Muffin Monster 10000. Before you begin be sure to read through these items to ensure a properly operating unit when installed.

- Clean housing bores thoroughly with solvent (Simple Green® or equivalent).
- Verify all parts/components being assembled (or reassembled) are clean and free of excess lubricant and gasket material.
- Inspect shaft top and bottom seal assemblies. Mating surfaces must be clean and polished.
- Inspect all parts for cracks, nicks, burrs, excessive wear, or obvious signs (or suspected areas) of damage. Replace all damaged/suspected parts. Sealed bearings cannot be re-greased - must be replaced.
- When a procedure specifies lubrication, refer to Table 4-2 for the recommended lubricant.
- Complete all required customer/user inspection records and forms if required.

### 6.2.1 Assembly Top End Housing

This section gives the steps for assembling the top end housing. Figure 6-1 is an illustration showing the parts the top end housing comprises. The circled numbers in this figure (and the following figures) correspond to the parts list shown in Table 6-2.

**FIGURE 6-1 TOP END HOUSING**




1. Lubricate the top end housing bores (2) and install the seal cartridges (6) into the top end housing.
2. Install the seal plates (5).
3. Apply three drops of Loctite Threadlocker Red 271 to the bolt fastener threads (21) and install.
4. Lubricate the O-rings (33) and install them into the grooves at the top of the shafts (7) near the hex.
5. Turn the end housing on its side.
6. Insert one of the shafts into the seal cartridge (it doesn't matter which shaft).
7. Install the retaining ring (22) in the shaft groove, ensuring that the side with the sharper

edge of the retaining ring faces away from the seal cartridge.

8. Repeat with the other shaft.
9. Install gears (8) and (9) on top of shafts (it doesn't matter which gear on which shaft at this point). See Figure 6-2.

**FIGURE 6-2 GEAR INSTALLATION**




10. Install keys (19).
11. Apply three drops of Loctite Threadlocker Red 271 to the bolt threads (28) and install the retaining hardware (14) and (28) to the top of the shafts.
12. The shaft with the smaller gear with drive lobes (9) is now the **drive shaft**.
13. Install the cutters and the spacers according to the procedure shown in Paragraph 6.2.2.

### 6.2.2 Install Cutters and Spacers


Install the cutters and spacers as follows, using Figures 6-3 and 6-4 as a reference.

**FIGURE 6-3 CUTTER/SPACER STACKING**



1. Position the top end housing/shaft assembly (2) as shown (upside down) so that the shafts are vertical and the threads are at the top. The drive shaft should be to your right as you face the **influent** side of the grinder.
2. Install the first spacer on the drive shaft as shown in Figure 6-3 and the first cutter on the driven shaft, orienting the cutters as shown in Figure 6-4.

**FIGURE 6-4 CUTTER ORIENTATION**




3. Install a spacer on the driven shaft and a cutter on the drive shaft, rotating the indexing dimple or notch by one position (Figure 6-4).
4. Continue until all cutters and spacers are installed - a spiral pattern results.
5. Lubricate the O-rings (33) and then install one each in the grooves at the top of the shaft near the threads (as was done at the other end of the shafts in Paragraph 6.2.1).
6. Set the assembly aside for now and prepare the main housing.

**6.2.3 Prepare Main Housing**

Follow these steps to prepare the main housing (see Figure 6-5 for reference).

**FIGURE 6-5 MAIN HOUSING**




1. Place the main housing (1) on its top so that the bottom of the housing faces up. Lubricate the bores and install the seal cartridges (6) into the bottom of the main housing.
2. Install the seal plate (5).
3. Apply three drops of Loctite Threadlocker Red 271 to the bolt fastener threads (21) and install with the lock washer (23).

4. Go to the next procedure to attach the main housing to the earlier assembled top housing with cutter stack.

#### 6.2.4 Attach Main Housing to Top Housing

The following steps show the procedure for attaching the main housing (1) to the top end housing (2) (use Figure 6-6 for reference).

**FIGURE 6-6 MAIN HOUSING TO TOP HOUSING ATTACHMENT**



1. Place the main body gasket (17) on the main housing (1).
2. Using a lifting device, carefully lower the main housing over the stack of exposed shaft ends, taking care to align the shaft hex with the hex socket in the seal cartridges. **THIS IS VERY IMPORTANT - USE CARE.**
3. Apply three drops of Loctite Threadlocker Red 271 to shaft threads and with finger-tight pressure install a flanged hex nut (20) on each shaft.

4. Fasten the top housing to the main housing using the provided appropriate fasteners (24) and (26).


5. Torque each shaft hex nut (20) to 135 ft. lb.

6. Install the bottom cover as explained in the next section.

#### 6.2.5 Install Bottom Cover

This section gives the steps to install the bottom cover. Follow the steps and use Figure 6-7 for reference.

**FIGURE 6-7 BOTTOM COVER INSTALLATION**



1. Place the bottom cover gasket (18) on the bottom cover (4).
2. Install the bottom cover and fasten with the provided appropriate fasteners (24) and (26).
3. Install the pipe plugs (31) in the main body (use teflon pipe thread).



4. Install the top cover. See the next section for top cover installation steps.

7. Install the drive motor according to the steps shown in the next section.

### 6.2.6 Top Cover Installation



### 6.2.7 Drive Motor Installation

The procedure below gives the steps for installing the top cover. Use Figure 6-8 for reference.

These steps give the procedure for installing the drive motor on the Muffin Monster 10000. Use Figure 6-9 for reference.

**FIGURE 6-8 TOP COVER INSTALLATION**

**FIGURE 6-9 DRIVE MOTOR INSTALLATION**




1. Position the assembly right side up so that the gears are now facing upward.
2. Apply grease to the gear housing and gears.
3. Apply a light coating of grease to the drive lobes of the drive gear (item 9 in Figure 6-8).
4. Place the top cover gasket (18) on the top cover (3).
5. Install and fasten the top cover (3) using the provided appropriate fasteners (24), (26), (27).
6. Install all four lifting eyes (15).

1. Place the drive gasket (16) on the top cover (3).
2. Install the interlocking coupling half (12) on the motor drive shaft.

3. Apply a light coating of gear grease to the lobes of the coupling half (12).
4. Install the drive motor (13) to the grinder top cover (3), orienting the motor as shown in Figure 6-9.
5. Fasten the drive motor using the provided appropriate fasteners.


### 6.3 GRINDER REMOVAL

The grinder can be removed from the installation without any disassembly and/or component removal. The following procedure describes the removal of the grinder from installation.



1. Verify that the main power is disconnected from the motor controller.
2. Attach the lifting cables to all hoisting rings on the top cover as shown in Figure 6-10.

**FIGURE 6-10 LIFTING WITH HOIST**



3. Disconnect the grinder at the inlet and outlet flanges.
4. Lift the grinder and set the grinder on the bottom cover on a level surface.

Replacing the grinder in the installation after assembly or maintenance is the same as the installation instructions in SECTION 3.

### 6.4 GRINDER COMPONENT REPLACEMENT

The following paragraphs contain procedures to replace grinder components. Place removed components on a clean, flat, work surface to avoid damage and facilitate inspection.

Refer to Figure 6-11 and Table 6-1 for grinder part location and parts list. Ensure that all mating surfaces are clean during grinder component replacement. Clean any gasket residue and replace gasket if required. It is always a good idea to have spare gaskets on hand in the event of damage when performing maintenance tasks.

#### 6.4.1 Main Body Removal and Replacement

Remove the main body of the Muffin Monster 10000 by following these steps:

1. Isolate the grinder from flow and remove from pipeline.
2. Remove the drive (in order to turn the unit upside down).
3. Cover the exposed gear opening to prevent grease contamination.
4. Turn the unit upside down.
5. Remove the bottom cover.
6. Remove the stack nuts from the shafts.
7. Remove the main body.

#### 6.4.2 Cutter and Spacer Removal

Perform the following procedure to remove and replace the grinder cutters and spacers. Refer to Paragraph 6.4.3 for cutter and spacer stacking.



**CUTTERS AND SPACERS ARE SHARP. APPROPRIATE GLOVES MUST BE WORN WHEN INSTALLING OR HANDLING CUTTERS AND SPACERS TO PREVENT INJURY DURING HANDLING.**

1. Isolate the grinder from flow and remove from pipeline.
2. Remove the drive (in order to turn the unit upside down).
3. Cover the exposed gear opening to prevent grease contamination.
4. Turn the unit upside down.
5. Remove the bottom cover.
6. Remove the stack nuts from the shafts.
7. Remove the main body.
8. Remove cutters and spacers.

#### 6.4.3 Stacking Cutters and Spacers

Verify that the correct quantity of cutters and spacers for the grinder are on hand. Refer to Table 6-2.

Verify all cutters and spacers are clean, free of cracks, signs of excessive wear, and/or other obvious signs of damage.

Verify the cutter drive and driven shafts are free of any burrs. File and clean off any burrs.

Follow the procedure given in Paragraph 6.2.2 for correct cutter and spacer stacking.



**Verify That Foreign Material Does Not Become Trapped Between the Stack Components. Trapped Material Can Affect Stack Height and Cutter Meshing Tolerance.**

#### 6.4.4 Gear and Shaft Removal and Replacement

Follow these steps for gear and shaft replacement.

1. Remove the main body and cutters/spacers as described in previous procedures.
2. Remove the retaining fasteners from the top of the shafts.
3. Remove the gears and keys.
4. Remove grease.
5. Remove the retaining ring from each shaft.
6. Remove the shafts.
7. Remove the shaft O-rings.
8. Reinstall the gears and shafts beginning with the Assembly - Top End Housing, Paragraph 6.2.1, and proceeding through the necessary steps.

#### 6.4.5 Top End Housing Removal

1. Remove the main body and cutters/spacers as described in previous procedures.
2. Remove the retaining fasteners from the top of the shafts.
3. Remove the gears and keys.
4. Remove grease.
5. Remove the retaining ring from each shaft.
6. Remove the shafts.
7. Remove the seal plate.
8. Remove the seal cartridges (a hydraulic press may be necessary to **remove** the seal cartridges - not for installation).

The top end housing is now isolated and is subject to maintenance or replacement.

#### 6.4.6 Seal Cartridge - Top, Inspection and Removal




1. Remove the top end housing as described in a previous procedure.
2. Remove the seal cartridge (a hydraulic press may be necessary to **remove** the seal cartridges - not for installation).
3. Inspect the cartridge and replace if necessary.

#### 6.4.7 Seal Cartridge - Bottom, Inspection and Removal

1. Remove the main body as described in a previous procedure.
2. Remove the seal plate.
3. Remove the seal cartridge (hydraulic press may be necessary to **remove** the seal cartridges, not for installation).
4. Inspect the cartridge and replace if necessary.

### 6.5 GRIND TEST

Perform a grind test per the following procedure before installing the grinder if the cutter assembly or cutters have been removed and replaced.





1. Temporarily connect the appropriate wiring to supply power to the grinder motor.
2. Apply power to the grinder. Verify the grinder is running with no excessive noise or vibration and cutters are rotating correctly.

3. Carefully insert a piece of wood into the grinder cutting chamber. Verify the wood is reduced by the cutters. Remove power.
4. Clean any debris left over from the grind test prior to installing the grinder as described in SECTION 3.

### 6.6 OPTIONAL MOTOR/REDUCER ASSEMBLY


One of the options JWC provides is an electric motor with reducer. The motor/reducer combination can be TEFC, SUPER-E, WASHDOWN, XPFC or immersible type. Figures 6-11 through 6-13 show the motor/reducer dimensions. Part numbers and part locations for the reducer and connecting hardware can be found on the drive assembly drawing in the drawings section of this document. Following is an exploded view of the grinder with part number callouts. The part numbers are shown in Table 6-1. There are different cutter options offered which allow for customization of the grinder for specific purposes. The cutter/spacer combination, type and quantity is shown in the cutter drawing in the drawings section of this document.

**FIGURE 6-11 OPTIONAL MOTOR/REDUCER DIMENSIONS**




I

**FIGURE 6-12 OPTIONAL TEFC, SUPER-E, WASHDOWN, XPFC MOTOR/REDUCER - EXTENDED SHAFT**



**FIGURE 6-13 IMMERSIBLE MOTOR**



**TABLE 6-1 ELECTRIC MOTOR DIMENSIONS**

Motor Type	HP	M1	M2	M3	WEIGHT
TEFC	2	11 3/16 (284)	7 3/16 (183)	9 3/8 (238)	41 (18.6)
	3	13 7/16 (341)	7 3/16 (183)	9 5/16 (237)	60 (27.2)
SUPER-E	2	10 7/8 (276)	8 (203)	10 3/8 (264)	59 (26.8)
	3	13 1/8 (333)	8 1/2 (216)	11 15/16 (303)	98 (44.5)
WASHDOWN	2	13 3/8 (340)	7 3/16 (183)	9 5/16 (237)	41 (18.6)
	3	13 7/16 (341)	7 (178)	9 5/16 (237)	62 (28.1)
XPFC	2	13 1/8 (333)	7 1/8 (181)	10 3/16 (259)	60 (27.2)
	3	16 1/4 (413)	8 5/8 (219)	11 13/16 (300)	91 (41.3)
IMMERSIBLE	2	15 3/4 (400)	11 7/16 (291)	17 (432)	205 (92.9)
	3	15 3/4 (400)	11 7/16 (291)	17 (432)	212 (96.2)
<b>REDUCER SPOOL DIMENSION INCLUDING ADAPER (D)</b>					
	2	9 (229)			
	3	11 15/16 (303)			

**FIGURE 6-14 MUFFIN MONSTER 10000-0004/0006 EXPLODED VIEW**




TABLE 6-2 MUFFIN MONSTER 10000 PARTS LIST

Item	Description	Part No.	Qty	Material
1	Main Housing - 4" Pipe / 6" Pipe	10036-0004/6-DI	1	Ductile Iron
2	Top End Housing	10077-DI	1	Ductile Iron
3	Top Cover	10005-DI	1	Ductile Iron
4	Bottom Cover	10027-DI	1	Ductile Iron
5	Seal Plate	10015	2	304 SST
6	Assembly - Seal Cartridge	A35620- SS	4	Tungsten Carbide
7	Drive Shaft	10018-0008	2	Alloy Steel
8	Gear/Coupling - 27 Teeth, High Strength	10019-0001	1	Alloy Steel
9	Gear - Driven - 34 Teeth, High Strength	10021-0001	1	Alloy Steel
10	Washer, Flat 3/8 ID x 1-1/2 OD	30184	2	Steel
11	Gasket - Main Body	10014-0036	2	C/R or Viton
12	Gasket - Top & Bottom Covers	10014-0005	2	C/R or Viton
13	Key, 5/16 SQ x 1-1/2	10045-0001	2	Steel
14	Hex Nut, Flanged, 1-14	30210	2	Steel
15	HHCS M6 x 1 x 20 mm, Full Thread	30693	8	18-8 SST
16	Retaining Ring, 5160-156	30287	2	Steel
17	Washer, Lock M6	30697	8	18-8 SST
18	HHCS M8 x 1.25 x 25 mm, Full Thread	30694	30	18-8 SST
19	Washer, Lock M8	21008-SS	30	18-8 SST
20	HHCS M10 x 1.5 x 16 mm, Full Thread	30695	2	18-8 SST
21	Plug, Pipe 1/2 NPT	31087-0016	6	Steel
22	Plug, Pipe, 1-1/2 NPT	31087-0015	2	Steel
23	O-Ring, #220	34046	4	Buna-N or Viton
24	Cutter Stack Assembly, Drive Shaft	See Drawing	1	
25	Cutter Stack Assembly, Driven Shaft	See Drawing	1	

This page intentionally left blank.



## APPENDIX A

### ELECTRIC DRIVE ASSEMBLY MAINTENANCE INSTRUCTIONS

#### A. 1 GENERAL INFORMATION

This maintenance instruction describes the standard and immersible electric motor drive assembly that provides rotary power for JWC Environmental (JWCE) high flow waste management devices such as grinders and augers. The electric drive assembly consists of an electric motor, reducer, an optional extended shaft and adapter spool. Refer to the electric drive assembly drawing for parts location and parts list.

The following paragraphs define the specifications, support guidelines, and safety concerns for the drive assembly. Details for the controller and the applicable JWCE equipment are located in the corresponding operation and maintenance manuals. Dimensional information for the drive may be found on the associated equipment configuration drawing.

**Electric Drive** - The following specifications apply to the electric drive.

- NEMA Frame, TEFC/TEXP / Chemical Duty / Super-E for standard motors or TENV XP for immersible motors.
- Speed: 1725 rpm for 60Hz (typical); 1440 for 50 Hz.
- Horsepower Rating: 1 to 10 horsepower.
- Power Requirements: 208/230/380/460 volts AC  $\pm$  10%, three phase, 50/60 Hertz.
- Duty: Continuous, grounding is required.
- Temperature: Operating 23° F (-5° C) to 105° F (40° C). Motor winding heater required below 32° F (0° C).
- Storage 40° F (5° C) to 105° F (40° C).
- Optional extended shaft available in six inch increments from 12" up to 120".

**Speed Reducer** - The speed reducer assembly consists of a motor adapter and a reducer. The following general specifications apply to the speed reducer.

- Input: 10 HP (maximum), 1450 to 1800 RPM.

- Reduction Factor: 377:1 (1 HP), 29:1 (3-5 HP), 43:1 (5 to 10 HP).
- Service Factor: 1.15.
- C-Face Adapter: NEMA 56C or 143TC (1 HP), 145TC or 182TC (3-5 HP), 213 or 215TC (5-10 HP).
- International Electro-technical Commission (IEC) 112M (Standard).

The spool is a one piece assembly that provides adaptability from the motor to the cutter assembly end housing and houses the coupling which transitions the motor output to the equipment input drive shaft.

The drive assembly is designed to operate smoothly and quietly. If any excessive noise or temperature rise is noted, stop operation and inspect the drive.

#### A. 2 TROUBLESHOOTING

Motor does not start:

- Main power supply trouble - Check the main power and motor controller settings.
- Motor failure - Contact JWCE.

Motor hums excessively:


- Supply voltage exceeds motor rating - Check supply voltage and line connections.
- Motor failure - Contact JWCE.

Motor overheating:



- Improper ventilation - Standard motors: Verify air intake is not blocked and motor cooling fan is rotating. Increase ambient air flow and reduce ambient heat if possible. Immersible motors: Verify motor body heat fins are free of dirt, sludge or other contaminants.
- Main power line problems or bad connection - Check supply voltage and line connections.
- Motor failure - Contact JWCE Customer Support.

**A. 3 REMOVAL AND REPLACEMENT GUIDELINES**

Observe the following guidelines during removal and replacement of the motor, reducer, and spool. Review the safety requirements in the JWCE equipment manual. Removed parts can be used during replacement unless damaged, worn or otherwise noted. Contact JWCE if any of the parts inspected in the following paragraphs appear damaged or worn.



**Opening The J-Box On Immersible-type Motors Will Void The Warranty. Change Motor Rotation Via The Controller. Refer To The Motor & Cable Wiring Diagram For Connection Definition.**

**VERIFY SUPPLY POWER HAS BEEN REMOVED AND TAGGED OUT BEFORE REMOVING MOTOR**



**DO NOT LIFT HEAVY EQUIPMENT OVERHEAD OF PERSONNEL.**

- Replacement of the motor or speed reducer does not require removal of the JWCE equipment from the installation.
- Store removed parts in a safe location.
- Install the JWCE equipment and electrical hookup following good practices and in compliance with all OSHA, local, state, and federal codes and requirements.
- Do not steam clean and disinfect the motor. Clean outside surfaces of the motor with suitable solvent.
- Remove all gasket material from all mating surfaces.
- Inspect outside of each unit/component removed for signs of cracks, damage, or excessive wear. Replace if necessary.
- Complete all required customer/user inspection records and forms.

**A. 4 DRIVE ASSEMBLY REMOVAL/REPLACEMENT**

Perform the following to remove the drive assembly as a complete unit from the JWCE equipment.

1. Attach lifting cables/sling lift to the drive assembly. Maintain tension on the lifting cables/sling.
2. Remove hardware securing drive assembly to the JWCE equipment.
3. Remove wiring from motor or at motor controller for immersible motors.
4. Lift up the drive assembly with slow and steady pull. Place removed assembly on a clean level surface and remove lifting cables/sling.
5. Inspect top cover gasket; replace if required.

Perform the startup and grinder cutter rotation verification as defined in the motor controller manual after motor replacement.

**A. 5 MOTOR REMOVAL / REPLACEMENT**

Each motor is maintenance-free type and is covered by the motor manufacturer's service policy and limited warranty. JWCE advises do not disassemble motor. If service is required, JWCE recommends removal of the motor from the affected unit and returning the motor to an authorized repair center. Contact JWCE Customer Support for more information.

Perform motor removal per the following steps. Replace the motor in the reverse order of the removal steps.

1. Prepare JWCE equipment for motor removal as described in SECTION 6.
2. Disconnect power leads to the motor and any heater or thermostat wiring (if required).
3. Remove hardware securing the motor to the spool.
4. Attach lifting cables/sling lift to the motor.
5. Remove the coupling guards from the speed reducer assembly.
6. Remove hardware securing the motor to the speed reducer assembly.
7. Slowly lift the motor from the speed reducer assembly and place the motor on a clean, flat work surface.

8. Remove motor flexible coupling half and key from the motor output shaft. The coupling half should be easily removable from the motor output drive shaft. If the coupling cannot be removed by hand, a gear puller will be required.
9. Inspect coupling motor half and motor output shaft key for damage. Discard and replace damaged components as necessary. **Store motor shaft half of coupling and motor output shaft key in a safe location to prevent loss until the motor is replaced on the motor/reducer adapter spool.**
3. Remove hardware securing the speed reducer assembly to the speed reducer/equipment adapter spool.
4. Slowly lift the speed reducer assembly from the adapter spool and place it on a clean, flat work surface.
5. Remove the lifting cables/sling lift from the speed reducer assembly.
6. Remove and discard the speed reducer assembly-to-spool gasket.

Perform startup and grinder cutter rotation verification after motor replacement.

#### A. 6 SPEED REDUCER AND SPOOL REMOVAL / REPLACEMENT

The reducer assembly consists of a motor adapter spool and a reducer. The reducer assembly and spool are considered a complete assembly. Component removal and/or replacement is not recommended. Replace the speed reducer and spool in the reverse order of the removal steps. Contact JWCE if a speed reducer or spool problem is detected or suspected.

Remove the speed reducer and spool per the following procedure. Replace discarded gasket when replacing the speed reducer.

1. Remove the electric motor.
2. Attach lifting cables/sling, lift from the speed reducer assembly if necessary.

7. Remove speed reducer assembly half of interlock coupling and key from the speed reducer assembly output shaft. Each coupling half should be easily removable from the shafts. A gear puller may be required if the couplings cannot be removed by hand.
8. **Store interlocking coupling and key in a safe location until the speed reducer assembly is installed.** Proceed to the next step if removing the spool.
9. Remove hardware securing the equipment adapter spool to the equipment top cover.
10. Slowly lift the equipment adapter spool from the unit top cover and place it on a clean, flat work surface.
11. Remove and discard the spool-to-top cover gasket.

Perform startup and grinder cutter rotation verification after spool replacement.

## IMMERSIBLE MOTOR & CABLE WIRING

LOW VOLTAGE	HIGH VOLTAGE										
<p style="text-align: center;">MOTOR</p> <p style="text-align: center;">T'STAT LEADS</p> <p style="text-align: center;">LINE</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">RED WHT BLK BLU ORG</p>	<p style="text-align: center;">MOTOR</p> <p style="text-align: center;">T'STAT LEADS</p> <p style="text-align: center;">LINE</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">RED WHT BLK BLU ORG</p>										
SINGLE VOLTAGE MOTORS	THERMOSTAT RATING										
<p style="text-align: center;">LINE</p> <p style="text-align: center;">T'STAT LEADS</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">CABLE</p> <p style="text-align: center;">RED WHT BLK BLU ORG</p>	<table style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="border-right: 1px solid black; padding: 5px;">AMPS</th> <th style="padding: 5px;">VOLTAGE</th> </tr> </thead> <tbody> <tr> <td style="border-right: 1px solid black; padding: 5px;">6.0</td> <td style="padding: 5px;">115</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">3.0</td> <td style="padding: 5px;">230</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">1.5</td> <td style="padding: 5px;">460</td> </tr> <tr> <td style="border-right: 1px solid black; padding: 5px;">1.2</td> <td style="padding: 5px;">575</td> </tr> </tbody> </table>	AMPS	VOLTAGE	6.0	115	3.0	230	1.5	460	1.2	575
AMPS	VOLTAGE										
6.0	115										
3.0	230										
1.5	460										
1.2	575										

# MODEL 10000-08

FLOW RATE (M<sup>3</sup>/HR)

7-02-15

